

# Startup of Remote I/O Modules


# Agenda

- **ADAM-4000/5000 Configuration and Utility**
- **ADAM-6000/5000TCP Configuration and Utility**
- **Communication Protocols**
- **Basic Trouble Shooting**

- **ADAM-4000/5000 Configuration and Utility**
  - Initial Mode
  - Utility Operation
- **ADAM-6000/5000TCP Configuration and Utility**
- **ASCII Command / Modbus RTU / Modbus TCP**
- **Basic Trouble Shooting**
- **Hands-on for Installation & Wiring**

# Utility Configuration

- Adam.Net Utiltiy
- In RS-485, the address of every module must be unique



# Initial Mode

- Why Using Initial Mode
- How to Set Initial
- Some Modes can only be configured under Initial mode






Figure 2-4 Set INIT switch to "Init"

# Utility with Initial Mode

- Just only one module can be set to initial mode
- Start sign means ID= 0




# Hand-On Practice

- **Objective : Utility Operation**
  - **Step1 : Set Module in Initial Module**
  - **Step2 : Use Utility to Search Module**
  - **Step3 : Change Baud rate, Address, and Protocol Setting**
  - **Step4 : Get I/O data**
- **Time : 5 Mins**

# Utility with Trend and Data Logging

- Trend View
- Data Logg





# Hands-On Practice

- **Objective : DI/O data & show AI/O data**
  - Step1 : Show trend
  - Step2 : Change the setting
  - Step3 : Data Log Operation
- **Time : 5 Mins**

- **ADAM-4000/5000 Configuration and Utility**
- **ADAM-6000/5000TCP Configuration and Utility**
  - Search module
  - Network Setting
  - Add Remote Devices
  - Firmware Update
  - Access Control
  - Adam-6K series New Functions
- **Communication Protocols**
- **Basic Trouble Shooting - Modscan**
- **Hands-on for Installation & Wiring**


# Utility Operation

- UDP Broadcast to search modules
- Works in the same sub-net
- Default IP: 10.0.0.1
- Network setting
- Default Password



# Firmware Update

- Firmware Update



# Access Control


- **Use IP or MAC address to control connected devices**
  - Permit one device with IP:172.18.2.90 to access




The screenshot shows a software interface for configuring access control settings. The top navigation bar includes links for Information, Network, RS-485/WDT, Stream/Event, Password, Firmware, Peer to Peer, and Access Control. The Access Control link is highlighted with a red box. Below the navigation, the 'Controlled By' section has two radio buttons: 'IP address' (selected) and 'MAC address'. There are 'Reset' and 'Apply' buttons. The 'Security IP/MAC Setting' section contains two entries. Entry 0 is highlighted with a red box and shows IP fields: 172, 18, 2, 90. Entry 1 shows IP fields: 255, 255, 255, 255. There are 'Apply' and 'Apply all' buttons for each entry.

Index	IP Address	Subnet Mask	Gateway	Default Router
0.	172	18	2	90
1.	255	255	255	255

# Utility Operation-Set AO Value




# Utility Operation-Read AI Value



# Advance I/O functions

- **Using Utility to change the modes**
- **DI : Latch, Frequency, Counter**
- **DO : Delay, Pulse Output**
- **AI : Max/Min/Ave**




# Adam-6K series New Functions

- Shorten Developing time
- Reduce software learning curve
- Cut down budget


**Advantech Providing  
P2P function and GCL Control**

# What is Adam Peer to Peer


- Instead of Master (Client)
- Actively update Input status to Output status
- DI channel to DO channel; AI channel to AO
- Only for Digital modules




# Passive Way – Continuously Polling



# Actively update Input status to Output status



# Adam-6K P2P in Adam.NET Utility




# ADAM-6K P2P Modes

- **Basic mode: one module every DI mapping to another module DO**




- **Advanced mode: DI/O mapping to multi module DO**



# What is GCL


- **Graphic Condition Logic**
- **UDP protocol control**
- **Graphically Pre-set Logic Rule**
- **Logic Rule directly installs in IO modules**

# With GOLiC Control Programming



# What is GCL

- UDP protocol control
- Graphically Pre-set Logic Rule
- Logic Rule directly installs in IO modules
- Including 4 parts:




# GCL Features


- **No Controller needed**
- **No Additional Software**
- **Simple Utility configuration**
- **Secured by IP or Mac address control**
- **Online Monitor**
- **One module includes 16 rules**
- **Rules in one module can be cascaded**
- **Rules can be expanded over modules**

# Control the Output

- Output can be **Local** or **Remote** module
- One module can have 16 logic rules



Local Output




Remote Output

TCP/IP Port: 1025



# Logic Rule Cascade

- At most 16 rules cascade in one modules



Rule 1





Rule 2



## Input




## Output



- **ADAM-4000/5000 Configuration and Utility**
- **ADAM-6000/5000/TCP Configuration and Utility**
- **Communication Protocols**
  - ASCII commands for Serial Modules
  - ASCII commands for Ethernet Modules
  - Introduction to Modbus Protocol
- **Basic Trouble Shooting - Modscan**

# ASCII commands for Serial Modules

- Follow Advantech ASCII Commands




# Hand-On Practice? (make sure if there is adam-5000)

- **Objective : Send ASCII Commands**
  - Step1 : Use utility to send
  - Step2 : Get module name & firmware version
  - Step3 : #AAN to read AI data from ADAM-4017
  - Step4 : #AASiCj(data) AO in ADAM-5024 ( #02S1C115.000 )
  - Step5 : \$AASi6 read DI from ADAM-5051
  - Step6 : #AASi1N01 Set DO-N On In ADAM-5056
- **Time : 10 Mins**

# ASCII commands for Ethernet Modules

- User could send the ASCII commands through TCP or UDP



# Introduction to Modbus Protocol

- **Modbus RTU**
  - For Advantech Serial Remote I/O modules
  - Standard Modbus Protocol, not Advantech protocol
- **Modbus TCP**
  - For Advantech Ethernet Remote I/O modules


# Introduction to Modbus Protocol

- **Data format**
  - ID, Function call, Data, Check Sum
- **Types of Data**
  - Coils; bit; Digital input output
  - Register; Word; 2 Bytes; 16 bits


Data address	Modbus address	Description
0X; 1X	00001...10000*	Coils (outputs)
3X	10001...20000*	Inputs
4X	40001...50000*	Holding registers

\* Maximum value is device dependent

# Modbus Address of Adam serial modules




# Modbus Address of Adam Ethernet modules





- **ADAM-4000/5000 Configuration and Utility**
- **ADAM-6000/5000TCP Configuration and Utility**
- **Communication Protocols**
- **Appendix – Intro of Modscan**
  - Get Data From ModScan tool

# Quick Startup


- Deciding the Connection method




- **Connection Setting**
  - IP for Ethernet
  - Port setting for Serial




- Example of Adam Analog Input - Adam-6017



- **Depending on device modbus address**
  - Device ID is 1 for Adam-6K series
  - Setup function code- 03 holding register
  - Setup Address and Length



- **Example of Adam Digital – Adam-6050**



- **Function code: 01**
- **Address (for Adam-6k series)**
  - DI starts from 01
  - DO starts from 17

ModScan32 - [ModSca6]

Address: 0017      Device Id: 1  
 MODBUS Point Type  
 Length: 6      01: COIL STATUS

For digital, device address is at 0X  
 Function code is 01

Usually DI starts from address 1  
 DO starts from 17

Lo...	Type	Value	Description	Mode
00001	Bit	1	DI 0	DI
00002	Bit	1	DI 1	DI
00003	Bit	1	DI 2	DI
00004	Bit	1	DI 3	DI
00005	Bit	1	DI 4	DI
00006	Bit	1	DI 5	DI
00007	Bit	1	DI 6	DI
00008	Bit	1	DI 7	DI
00009	Bit	1	DI 8	DI
00010	Bit	1	DI 9	DI
00011	Bit	1	DI 10	DI
00012	Bit	1	DI 11	DI
00017	Bit	1	DO 0	DO
00018	Bit	0	DO 1	DO
00019	Bit	0	DO 2	DO
00020	Bit	0	DO 3	DO
00021	Bit	1	DO 4	DO
00022	Bit	0	DO 5	DO

# Thanks~~~~